















EN Operating Instructions
Siedle Scope

S 850-0

Overview
Display and navigation

 	 	 	 
Phone volume Setting the volume for the receiver and handsfree calls.	Main menu Access to the call list, intercom settings, general settings and phone-book.	Phonebook Access to favourite telephone numbers.	Intercom menu Access to building communication functions (e.g. control and switching).


Navigation in all menus

	Use the cross-shaped control pad and the Enter button in the centre to navigate through all the menus in the cordless handset.
	Activate your selection using the round Enter button in the centre of the cross-shaped control pad or alternatively using the display button OK or Save .
	Leave the menu level and jump one menu level higher without saving your input using the red End call button or alternatively with the display button Back .
	Selected menu points, functions or names in the display have a yellow frame or are shown in yellow. In these operating instructions, these are depicted with a grey frame.

• Handling instructions are preceded by a point.



Overview

Model: Siedle Scope



Overview

Display




Standby mode


In the standby status, the cordless handset shows the time and date in the display, the 4 symbols of the main menu and 2 frequently used functions using display buttons, if these have been set up.


Status indications in the display


The current Siedle Scope status displays are shown along the top of the screen. The reception quality to the base station and the battery charge status are continuously shown. Other functions appear in the form of symbols only when active.

Symbols in the standby mode


 **Volume**
The receiver and handsfree volume are set using the Call volume menu.


 **Main menu**
Access to the call list, intercom settings, general settings and phonebook.


 **Phonebook**
Access to favourite telephone numbers.


 **Intercom menu**
Access to building communication functions (e.g. control and switching).

Status indications in the display


 **Reception quality**
Very good to none


 **Battery charge status**
100 %, 80 %, 60 %, 40 % and almost empty


 **Keypad lock**
The keypad lock prevents unintentional operation of the telephone.


 **Missed calls**
All calls are counted up to the number nine. If there are more than 9 calls, a plus symbol is shown after the 9.

Status indications in the display

 **Door call forwarding enabled**

 **Service not available**
Required service cannot currently be used (e.g. external line engaged).

 **Doormatic: enabled**

 **Call silencing: Activated**

Contents

Overview		Phone volume	15	Making a call to a phonebook entry	38
Display and navigation				Change entry	39
Model: Siedle Scope		Main menu	16	Deleting an entry	39
Display		Call lists	16	Intercom menu	40
		Intercom settings	18	The individual symbols in the Intercom menu	40
Siedle Scope	4	Doormatic	18		
One for all	4	Door call forwarding	19		
		Door call forwarding to the public network telephone	19	Frequently asked questions	42
Safety remarks	5	Functions	20		
Disposal	5	Door	21	Index	43
		Control Device	21		
Getting started	6	Function	21		
Registering the cordless handset at the base station	6	Settings	22		
Charging the cordless handset battery	6	Status	22		
Registering additional cordless handsets at the base station	6	Setting the time	23		
Switching the cordless handset on and off	7	Date settings	24		
Incoming calls	8	Audio settings	25		
Keypad lock	8	Ringtones	25		
Dial the required number	8	Phone volume	26		
Holding a call	8	Notifications	27		
Handsfree	8	Key tones	27		
Call silencing	9	Battery tone	27		
Volume	9	Signal tone	27		
Microphone silencing	9	Speed dial	28		
Call parking	9	Making a speed dialling call	29		
Call forwarding	10	Frequently used functions	29		
Ending a call	10	Language	31		
Brokering	11	System	31		
Cordless handset	11	ECO mode	32		
Charging cradle	11	Change PIN	32		
Door release	11	Resetting the base station	34		
Setting the date and time	12	Door call	35		
Setting the time	12	Deregistering / registering a handset	35		
Date settings	13	Dialling pause	35		
Video	14	External line digit	36		
		New entry	37		
		Phonebook options	38		

Technical additions or printing errors do not constitute grounds for compensation claims.

Customer service in the Furtwangen factory
+49 7723 63-375

These instructions are intended to supplement:

- The Scope product information
- The In-Home bus: Video system manual

The relevant current edition is located in the download area on www.siedle.de

Siedle Scope

One for all

A new freedom

Siedle Scope is a **video indoor station** and a **landline telephone** in one device. And it's cordless. That means that wherever you are, whether in the kitchen, the bathroom, the garden or the cellar ... Scope gives you a live update of who is standing at the door. Scope thus offers all the functions of a video indoor station, including a hands-free function and a door release button. At the same time, Scope is a fully-fledged landline telephone with excellent voice quality and countless Comfort functions. One for all. New freedom.

Scope, the **mobile video indoor station**

- Large colour display
- Video monitoring with zoom and swivel function
- Hands-free function
- In-house function control, such as lighting, garage door or blinds
- Can be extended: up to 8 handsets can be used in parallel

Scope, the **cordless landline telephone**

- High range and excellent voice quality thanks to the DECT standard
- Hands-free function
- Ergonomically optimized design and user guidance
- ECO mode with reduced transmission power
- Telephone book, call log and numerous other telephone functions
- Compatible with telephones from other manufacturers using the GAP profile, manufacturer-specific features only partially possible.

Scope of delivery

Siedle Scope cordless DECT telephone with door video function for the In-Home bus. Comprising a **base station, cordless handset and charging tray**. Scope unites the worlds of **door communication and public network telephony**, it is a comfort video in-house telephone and DECT telephone in one. You will also find the necessary connecting cables:

- 2 power supply units
- 1 public network cable
- 1 patch cable

Performance features

- Exclusive design with high-grade materials and fine workmanship
- High range and excellent speech quality thanks to DECT standard
- ECO mode with reduced transmission output
- Energy-saving line rectifiers (max. 0.5 W no load)
- Range outdoors up to 300 m, indoors up to 50 m
- Video surveillance with digital zoom
- Door call forwarding, e.g. to a mobile phone, also for door calls including door release (PIN-protected)
- Control of house functions such as light, garage door or roller shutters
- Communication between Scope and all other In-Home devices in the same line
- Doormatic
- Upgradable: Up to 8 cordless handsets in parallel
- Compatible with DECT telephones of other makes in compliance with GAP profile
- Operation possible with and without telephone system

Cordless handset performance features

- Individual design concept with six design variants
- Large 5.5 cm colour display, 240 x 320 pixel, illuminated
- Illuminated keypad
- Hands-free function
- Charging cradle with illuminated control buttons (call acceptance and door release)
- 8 ringtones
- Phonebook for 50 entries
- Caller list including date and time
- Last number redial
- Optional menu language setting
- Date and time display
- Signal strength display
- Caller display (clip)
- Li polymer battery
- Battery life on standby up to 100 h

Note

The Scope cordless handset must be kept with the same care and security awareness as a house key, as it can also open your front door from the outside. Ensure that it does not fall into unauthorized hands!

Safety remarks

Danger



Mounting, installation and servicing work on electrical devices may only be performed by a suitably qualified electrician. Failure to observe this regulation could result in the risk of serious damage to health or fatal injury due to electric shocks.

Danger



- Keep the charger away from sources of heat and naked flames!
- Never immerse the battery in water or salt water!
- Never dismantle or modify the battery or expose it to heat!
- Avoid dropping the battery if at all possible!
- Protect the battery from knocks or impacts, as these can damage the housing!
- Otherwise there is a risk of explosion or battery leakage, which could result in fire, injury or damage to the surroundings.
- If a battery leaks and the emerging substances come into contact with the eyes, mouth, skin or clothing, rinse the affected area immediately using water and consult a doctor.
- Only charge the battery in the cordless handset using the provided charging cradle and the original power supply unit.
- The charging cradle and the power supply unit were developed exclusively for use with the Siedle Scope cordless handset.
- Never use in conjunction with other products or batteries!
- A risk of overheating and deformation exists which could cause fires or initiate electric shocks.
- Do not expose the device to overheating or excessive pressure!

Warning



- Operating the device not in accordance with its intended purpose can cause injury.
- Do not drop or throw the devices!
- Do not use the devices if they are damaged, for example if the device housing has been damaged (sharp edges or exposed parts)!

Warning

- Install the base station in a dry and dust-free location away from direct sunlight.
- Siedle Scope is not suitable for use in wet rooms or in areas with an explosion risk.
- The cordless handset and the base station must be set up at least one metre away from other electrical devices.
- When used close to medical devices, functional disturbances can occur. In such cases, contact your specialist dealer or electrical installer!
- Only ever use original Siedle power supply units which form a part of the scope of supply.
- Only use the original Siedle rechargeable battery in the cordless handset.
- Do not hold the back of the cordless handset against your ear when it rings or when using the handsfree function! This can result in serious damage to your hearing.
- When using in conjunction with a hearing aid, it is possible for humming or feedback noises to occur.
- If the device requires servicing, contact your specialist dealer or electrical installer!
- Modern furniture is coated with an enormous variety of different lacquer and plastic finishes. Constituents of these materials can result in softening of the plastic feet in table-top devices and so impair the surface of the furniture. Please appreciate that the manufacturer is unable to accept any liability.

Disposal





- All electrical and electronic devices must be disposed of separately from the general house waste at the specially provided municipal waste facility.
- If a product bears the symbol of a waste bin with a line through it, then it falls under the regulations of European Directive 2002/96/EC.
- Responsible disposal and separate collection of end-of-life devices help to prevent potential environmental and health hazards, and form the basis for the recycling of used electrical and electronic devices.
- Rechargeable batteries should also not be disposed of with the general household waste.
- When disposing of your end-of-life devices and batteries, please observe the local waste disposal regulations. Details can be obtained from your local authority, waste disposal service or the specialist dealer from which you purchased the product.
- Before disposing of rechargeable batteries, cover over the contacts with sticky tape or other insulating material to ensure they do not come into direct contact with other objects. Direct contact with other metal objects in waste containers can result in fire and explosions.

Getting started

Registering the cordless handset at the base station

Your cordless handset is already registered in the set: The left-hand signal strength symbol indicates the strength of the connection in the status bar at the top.





Charging the cordless handset battery

After unpacking the cordless handset, the battery charge status must be checked. This is delivered fully charged, but discharge may have occurred during storage and transport.

Registering additional cordless handsets at the base station

Up to 8 cordless handsets can be operated in parallel at the base station. The cordless handset supplied as standard in the set is designated handset 1. Other cordless handsets are numbered through in the order in which they are registered. The prescribed designations for handsets 1 to 8 cannot be edited.



Procedure:

- If the display of the cordless handset shows the following message highlighted in yellow: **Base not found**, then connect the base station to the mains power.
- Also connect the charging cradle with the cordless handset to the mains power.
- As soon as the base station has been located, you can begin to use the cordless handset.
- If the registration has failed, contact your specialist dealer or electrical installer.

Note

Please observe the safety and disposal instructions relating to the rechargeable battery.

This is a li-polymer battery with the following performance capability:

- Standby: appr. 100 hours
- Video link: appr. 3 hours
- Audio link only: up to appr. 10 hours

Procedure:

- To register an additional cordless handset, disconnect the base station from the mains power.
- Reconnect the base station to the mains power.
- The base station now has a 3-minute window in which an additional cordless handset can be registered. This is indicated by a green flashing LED at the top.
- Also connect the charging cradle with the cordless handset to the mains power.
- The following message appears on the display on the additionally registered cordless handset:
 - Would you like to register the handset?
 - Confirm by pressing the left-hand display button OK.

Getting started

Registering additional cordless handsets at the base station

The following display appears during the registration process:

Searching base

Please wait

After selecting the base, the following display appears:

Registering handset

Please wait

- As soon as the base station has been found, confirm the located base with the left-hand display button OK.


The cordless handset is now in the ready status.

After successful registration, the base station is locked again for new registrations. This is indicated by a continuous green LED light.

- To register additional cordless handsets, disconnect the base station from the mains power again and proceed as described above.

Note

The additionally registered cordless handsets are synchronized to the correct date and time and the same intercom settings as cordless handset 1.



Switching the cordless handset on and off

During the switching on process, a progress bar appears on the display.



Procedure:

- In order to switch on the handset, press the red End call button for around 1 second.
- The handset automatically activates the power save mode if it is in the idle status for more than 2 minutes.
- The display switches off.
- A hibernating handset switches back on automatically as soon as it is placed in the charging cradle.
- The display terminates the power saving mode automatically after around 1 second as soon as it is removed from the charging cradle.


Getting started

Telephony

Switching the cordless handset on and off

Incoming calls

The call number is visible in the display, provided the caller has not withheld their number. If you have stored the call number with a name in the Scope phonebook, the name of the caller can be read in the display.



- If a display is in the power saving mode, the first time a button is pressed this only reactivates the display and has no other function.

Procedure:

- Incoming calls are picked up using the green Pick up button.
- If you pick up the call by pressing the Mouth button, the call will be held in the handsfree mode.
- If the cordless handset is in the charging cradle, the call can also be picked up using the Mouth button on the charging cradle.

Keypad lock

The keypad lock prevents unintentional operation of the telephone.



The keypad lock switches off automatically when you receive an incoming call. At the end of the call, it switches back on again.

Procedure:

- To lock and unlock the keypad, hold down the Hash button until the Key symbol in the status bar at the top of the display appears / disappears.

Note

If the keypad lock is switched on, it is also not possible to call emergency numbers.

Dial the required number



Procedure:

- Enter the required call number using the numerical keypad.
- After entering the first numbers, these are indicated by the display.
- Corrections can be made using the display button <C>.

Holding a call



Procedure:

- To establish a call, press the green Pick up button.

Handsfree

If the handsfree mode is active, the mouth symbol is highlighted in yellow.



Procedure:

- To establish a call in the handsfree mode, press the left-hand display button with the mouth symbol.
- If the handsfree mode is active, the mouth symbol is highlighted in yellow.

Getting started

Telephony

Call silencing

If required, all ringtones can be muted.

Incoming calls are then only signalled optically at the display.




Procedure:

- To switch the muting function on and off, hold down the Star button until the bell symbol in the status bar at the top of the display appears / disappears.

Volume

Using the symbols + and - it is possible to increase and decrease the volume of the current call; Depending on the call mode, this affects either the receiver or the handsfree speaker volume.



Procedure:

- Using the left-hand control button, select the **minus symbol**, or with the right-hand control button select the **plus symbol**.

The volume can be set in 8 stages.

Microphone silencing

Using the microphone silencing function, you can mute the cordless handset in the middle of a call should you wish to speak privately to a person in the room. The person at the other end is unable to listen in. The microphone symbol is highlighted in yellow when the microphone silencing function is active, and the cordless handset gives off a warning signal tone.



Procedure:

When using the telephone, select the **microphone symbol** with the line through it on the display using the upper control button.

Call parking

The dot button is the so-called "Flash" button. The function initiated by the "Flash" button depends on the telephone system to which the Scope is connected. Depending on the configuration, for example, it can be used to park the call to confer with a third party user, to whom the call is then forwarded. Any telephone connected to a PBX extension of the telephone system can be a third party user. Forwarding to a different Scope cordless handset registered at the same base station is carried out using the **Transfer** display button.



Procedure:

- Select the dot symbol using the lower control button.
- Select the telephone number of the user to which you wish to forward the call.
- To establish a call, press the green Pick up button.
- For successful call forwarding, terminate the conference by pressing the red End call button.
- If, alternatively, you wish to return to the waiting call, press the Dot button again.

Getting started

Telephony

Call forwarding


Any incoming calls, whether from public network telephones or door calls, as well as calls from other bus telephones, can be forwarded to other Scope cordless handsets.



Call transfer

- If you have picked up a call, to forward the call activate the **Forward** call display button.
- The submenu „**Call forwarding**“ appears showing a list of available handsets.
- Use the control buttons to select the handset to which you wish to forward the call.
- Confirm by pressing the left-hand display button OK.
- The call to the selected handset is established.
- As soon as the call to the selected handset is established, confirm the completed call forwarding process by pressing the red End call button.

Door call forwarding



- If you have picked up a door call, to forward the call activate the **Options** display button.
- The submenu **Options** opens up.
- Select the menu item **Forwarding** using the lower control button.
- Now use the control buttons to select the handset to which you wish to forward the call.
- Confirm by pressing the left-hand display button OK.
- The call to the selected handset is established.
- As soon as the call to the selected handset is established, confirm the completed call forwarding process by pressing the red End call button.

Ending a call

Calls are ended using the red End call button.



Note

Forwarding is not possible if there is no active call (blind transfer).

Procedure:

- To end the call, press the red End call button.
- If you are speaking in the hands-free mode with the handset in the charging cradle, end the call by pressing the Mouth button on the charging cradle.

Getting started

Telephony

Brokering

Brokering is used to describe the process of switching backwards and forwards between a door call and a public network call.



- Accept the door or public network call with the green Pick up button.
- By pressing the green Pick up button again, you can accept the second incoming call.
- The green Pick up button can be used to switch backwards and forwards between the 2 active calls.
- By actuating the red End call button, you can refuse the incoming second call.

Cordless handset

Idle status

In order to save power and to extend the life of the battery, the display is switched off in the idle status. The display switches off automatically around two minutes after the last action.

As soon as a call is received or information is transferred, the display is automatically activated to the ready status.


Note

If a display is in the power saving mode, the first time a button is pressed this only reactivates the display and has no other function.

Charging cradle

The charging cradle of your Scope cordless handset is used to charge the battery and offers two additional control buttons.

The control buttons are only operational and alight when the cordless handset is placed in the charging cradle and the charging cradle is supplied with power through the power supply unit.



Procedure:

- Without picking up the cordless handset, accept the incoming call using the **Handsfree button** on the charging cradle.
- End the call by pressing the **Handsfree button** again.
- Open the door using the **Door release button**.

Door release



The front door or storey door is opened, depending on where the door call comes from, using the Door release button with the key symbol.

The front door can be opened using the white Door release button even if there is no incoming door call.

There is an additional Door release button on the charging cradle. However, this only works if the cordless handset is located in the charging cradle.

Getting started

Setting the date and time

Setting the date and time

The date and time are required in order to show the correct time against incoming calls in the call list.



Main menu

OK

Back

Procedure:

- Using the right-hand control button, select the Main menu.
- In the Main menu, select the settings by pressing the right and then the lower control button.
- Confirm by pressing the left-hand display button OK.

Setting the time

Settings

Status

Date and time

Audio settings

Speed dial

Language

System

OK

Back

Procedure:

- In the Settings menu, select the date and time using the lower control button.
- Confirm by pressing the left-hand display button OK.

Date and time

Time

Date

OK

Back

- The **Time** entry is selected in the Date and time menu.
- Confirm by pressing the left-hand display button OK.

Getting started

Setting the date and time

Setting the time

Time settings

Hour

Minute

Save

<C

- The display shows the current date and time settings. These can be deleted using the display button <C.
- Enter the current time using the numerical keypad, e.g. 17 for the **hour**.
- Then select the **Minute** settings using the lower control button and enter for instance 25.
- Confirm by pressing the left-hand display button **Save**.
- The display confirms your entry with the message: Time set, and shows the entered **time setting**.
- Confirm by pressing the left-hand display button OK.

Date settings

Date and time

Time

Date

OK

Back

- In the main menu, select the **Settings symbol** by pressing the right and then the lower control button.
- Confirm by pressing the left-hand display button OK.
 - In the Settings menu, select the **date and time** using the lower control button.
 - Confirm by pressing the left-hand display button OK.
 - Select the **date** using the control button.
 - Confirm by pressing the left-hand display button OK.

Date settings

Year

Month

Day

Save

<C

- The display shows the current date and time settings. These can be deleted using the display button <C.
- **Year:** Enter the current year using the numerical keypad.
- **Month:** Select Month using the lower control button and enter the current month using the numerical keypad.
- **Day:** Select Day using the lower control button and enter the current day using the numerical keypad.
- Confirm by pressing the left-hand display button **Save**.
- The display confirms your entry with the message: **Date set**, and shows the entered date setting.
- Confirm by pressing the left-hand display button OK.


Getting started

Video

Video

When a call arrives, the Scope cordless handset rings and shows the video image. After pressing the green Pick up button or the Handsfree button with the mouth symbol, the speech connection is established.

If another door call is received from a different door, the existing call is ended and the process begins again.



Digital zoom

When you have accepted the video link from the door station, the Digital zoom function allows you to enlarge excerpts of the display image.

The zoomed image excerpt can be defined as the standard setting. In this case, when the next door call is received, the video image starts with precisely this image excerpt.

Procedure:


- Using the central control button, zoom into the video image.
- Select the required image excerpt using the upper, lower, left and right control buttons.
- Actuating the control button again disables the zoom function.
- You can define the activated digital zoom as the default setting.
- Open the menu using the **Options** display button.
- Select Set as default and confirm your selection with OK.
- To delete the default image excerpt, open the Options menu.
- Select **Disable zoom**.
- Confirm by pressing the left-hand display button OK.

Phone volume

Using the upper control button, select the submenu Phone volume.




Earpiece volume



Procedure:

- Using the right and left control buttons (+ and -), set the volume in 8 stages.
- If you wish to adopt a value, confirm this using the left-hand display button **Save**.

Handsfree



- Using the lower control button, select **Handsfree volume**.
- Using the right and left control buttons (+ and -), set the **handsfree volume** in multiple stages.
- If you wish to adopt a value, confirm this using the left-hand display button **Save**.

Main menu
Call lists



- Procedure:
- Using the right-hand control button, select the main menu.
 - The main menu offers quick access to:
 - **Call lists**
 - **Intercom settings**
 - **General settings**
 - **Phonebook**

or

- Access the **call lists** by pressing the green Pick up button from the ready status.

Call lists

The call list logs incoming and outgoing calls with call number, date and time.

The call list is subdivided into a number of different lists: Incoming calls, outgoing calls, missed calls and all calls.


	All calls
	Missed calls All calls are counted up to the number nine. If there are more than 9 calls, a plus symbol is shown after the 9.
	Outgoing calls
	Incoming calls

Main menu

Call lists

Call lists

The **Call lists symbol** is highlighted in yellow in the main menu.




Procedure:

The **call list symbol** is highlighted in yellow.

- Confirm by pressing the left-hand display button OK.

First of all the complete call list is displayed.

- In the status bar of the display, the symbols for different call lists are indicated.
- Use the right and left control buttons to switch between the different list types.
- The active list is the one highlighted in yellow in the status bar of the display.
- To call back, select the required user by highlighting in yellow with the control button and press the green Pick up button.



- To edit the call lists, press the **Options** display button.
- Here, the following functions are offered:

- **Call**
- **Delete**
- **Delete list**
- **Save to phonebook**

Main menu

Intercom settings

- Using the right-hand control button, select the main menu.
- The main menu offers quick access to:
 - **Call lists**
 - **Intercom settings**
 - **General settings**
 - **Phonebook**



Intercom settings

The Intercom settings menu is used to carry out user-specific inputs for switching and control operation with your Scope cordless handset. These functions have to be set by your electrician.




- In the main menu, select the **Intercom settings** using the control buttons.
- Confirm by pressing the left-hand display button OK.

Doormatic


The Doormatic menu is used to activate and deactivate the Doormatic once this function has been enabled by your electrical installer.

If the Doormatic function is enabled, in the ready status the Doormatic symbol appears in the status bar of the display.

The Doormatic setting applies to all the cordless handsets registered to the base station and is displayed in the display status bars of the different handsets.



- The **Doormatic** entry is selected.
- Confirm by pressing the left-hand display button OK.
- Using the right or left control button, select Yes or No. Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.
- The following message appears in the display: **Doormatic enabled/disabled.**
- Confirm by pressing the left-hand display button OK.



Note

Despite the Doormatic function being enabled, the door call continues for around 40 secs. If you wish to switch off the call, then set the front door volume to 0. This is done in the **Main menu > Settings > Audio settings > Front door**, or alternatively mute your Scope cordless handset using the Star button. However, please note that this will also mute all other incoming calls.

Main menu

Intercom settings



Door call forwarding

In the Door call forwarding menu, the door call is automatically forwarded to the public network telephone. This function exists exclusively for door calls; a door call can only be forwarded to a public network telephone.

If you also wish to use the Door release function from your public network telephone, you will have to enter your individual PIN.

Note

If door call forwarding is activated, your Scope cordless handset will no longer ring.



Procedure:

- In the **Intercom settings** menu, select the entry **Door call forwarding** using the control button.
- Confirm by pressing the left-hand display button OK.

- Using the right or left control button, select **Yes** or **No**. Your selection is highlighted in yellow.

- Confirm by pressing the left-hand display button OK.

The **Door call forwarding menu** shows the forwarding addresses from your phonebook.

- Select an **entry** using the lower and upper control button.
- or

- By selecting **New entry**, you can create a new forwarding address with a name and telephone number.

- Confirm by pressing the left-hand display button OK.

The following message appears in the display: **Door call forwarding enabled**, accompanied by the relevant name to which you wish to forward the calls, or **disabled**.

- Confirm by pressing the left-hand display button OK.

Door call forwarding to the public network telephone

If the Door call forwarding function is activated, your front door can be opened from your public network telephone.

For security reasons, this is only possible using an individual PIN.



- Pick up the door call at your public network telephone.
- For door release, enter your **4-digit pin** using the numerical keypad.
- Press the **Hash button**.
- Your front door will be opened from your public network phone.



- End the door call with the button combination * 0 # before replacing the receiver with the red hang up button, as otherwise the public network engaged tone will be audible at the door until timeout.

Main menu

Intercom settings

Functions

The Functions menu lists the control functions and the internal call functions which have been set up by your electrical installer. It also provides information about function numbers which are still unassigned and can therefore still be used. It is also possible here to delete functions you no longer require.

Functions 1 and 2 are preset with a default assignment. Both these functions can, however, be edited by your electrical installer if you require.

Functions

1 Light

2 Last door

3

4

5

6

7

OK

Back

- Procedure:
- In the Intercom settings menu, select the entry **Functions** using the lower control button.
 - Confirm by pressing the left-hand display button OK.
 - Select an unassigned function number in the Functions menu.
 - Up to 15 functions are possible.
 - Confirm by pressing the left-hand display button OK.

Name

When selecting, only choose unassigned functions. Take care not to overwrite previously set functions by mistake.

New entry

Name

Type

Function

3

OK

<C

- In the **New entry** menu, the Name entry is selected.
- Using the letter buttons, enter an unambiguous name for the required function, such as Open garage or Front door light.
- The name must not begin with a space or a special symbol.

Type

In the Type submenu, assign the function to the relevant function type. On principle, any function can be linked to any function type. By selecting the right type, you ensure that the cordless handset displays the correct user interface when executing the function.

- There are 3 possibilities to choose from.
- Wired
 - Door
 - Control Device

Type

Wired

Door

Control Device

OK

Back

- Select **Type** entry using the control buttons.
- Access the possible function types using the OK display button.
- Select **Wired** entry using the control buttons.
- Confirm by pressing the left-hand display button OK.

Wired

Select this function type if you wish to call a different bus telephone using the function.

Main menu

Intercom settings

Door

Select this function type if the function is to be used to dial a door.

New entry

Name

Type

Door

Function

3

OKBack

- Select **Door** entry using the control buttons.
- Confirm by pressing the left-hand display button OK.

Control Device

Select this function type if the function is to be used to switch a control device.

New entry

Name

Type

Function

3

OKBack

- Select Control device entry using the **control buttons**.
- Confirm by pressing the left-hand display button OK.

Function

Assignment to the required function number is carried out in the Function submenu. The function number must be identical with the programmed value in the bus programming software BPS 650-...; in total up to 15 functions can be programmed.

New entry

Name

Type

Function

3

SaveBack


The function number is pre-assigned by your selection. Select this using the lower control button.

Now save your complete entry by pressing the left hand display button **Save**.

Main menu
Settings

In the Settings menu, you can obtain information about your cordless handset and carry out general settings required for running operation. The following menu points are available:

- **Status**
- **Date and time**
- **Audio settings**
- **Speed dial**
- **Language**
- **System**




- Using the right-hand control button, select the Main menu.

- In the main menu, select the **Settings symbol** by pressing the right and then the lower control button.
- Confirm by pressing the left-hand display button OK.


Status

The Status menu provides information about the model, the used software and firmware, the charge status of the battery, and enabled / disabled functions (Doormatic and call forwarding).



The **Status** menu is highlighted in yellow.

- Confirm by pressing the left-hand display button OK.




Main menu

Settings

Setting the date and time


The date and time are required in order to show the correct time against incoming calls in the call list.



Procedure:


- Using the right-hand control button, select the Main menu.
- In the Main menu, select the settings by pressing the right and then the lower control button.
- Confirm by pressing the left-hand display button OK.

Setting the time



In the **Settings** menu, select the **date and time** using the lower control button.

- The **Time** entry is selected in the Date and time menu.
- Confirm by pressing the left-hand display button OK.



- The display shows the current date and time settings. These can be deleted using the display button <C.
- Enter the current time using the numerical keypad, e.g. 17 for the **hour**.
- Then select the **Minute** settings using the lower control button and enter for instance 25. Only plausible entries are possible.
- Confirm by pressing the left-hand display button **Save**.
- The display confirms your entry with the message: **Time set**, and shows the entered time setting.
- Confirm by pressing the left-hand display button OK.

Main menu
Settings

Date settings

Date and time

Time

Date

OK

Back

Date settings

Year

Month

Day

Save

<C

- Procedure:
- In the main menu, select the **Settings symbol** by pressing the right and then the lower control button.
 - Confirm by pressing the left-hand display button OK.
 - In the Settings menu, select the **date and time** using the lower control button.
 - Confirm by pressing the left-hand display button OK.
 - Select the **date** using the control button.
 - Confirm by pressing the left-hand display button OK.

- The display shows the current date and time settings. These can be deleted using the display button <C.
 - **Year:** Enter the current year using the numerical keypad.
 - **Month:** Select Month using the lower control button and enter the current month using the numerical keypad.
 - **Day:** Select Day using the lower control button and enter the current day using the numerical keypad.
 - Only plausible entries are possible.
 - Confirm by pressing the left-hand display button **Save**.
 - The display confirms your entry with the message: **Date set**, and shows the entered date setting.
 - Confirm by pressing the left-hand display button OK.
-
- Pressing the red End call button takes you back to the higher-level menu without saving.

Main menu

Settings

In the **Settings** menu, you can obtain information about your cordless handset and carry out general settings required for running operation.

The following menu points are available:

Status


Date and time

Audio settings

Speed dial

Language

System



Procedure:

- Using the right-hand control button, select the Main menu.

- In the **main menu**, select the **Settings symbol** by pressing the right and then the lower control button.

- Confirm by pressing the left-hand display button OK.

Audio settings


The Audio settings menu is used to carry out acoustic settings, adjust the call volume and to assign different melodies to different call types. There are 8 different melodies available to choose from for the different types of call.

The following menu points are available:

Ringtones

Call volume setting

Signal tones



- Select **Audio settings** in the Settings menu using the lower control button.

- Confirm by pressing the left-hand display button OK.

- Select **Ringtones** in the **Audio settings menu** using the control button.

- Confirm by pressing the left-hand display button OK.

- Select the required entry in the **Ringtones menu** using the control buttons.

- Confirm by pressing the left-hand display button OK.

Ringtones


Acoustic settings are performed for:

Telephone

Storey call

Intercom

Front door



Procedure:


- Using the right and left control buttons (+ and -), set the volume in 8 stages.

- If you wish to adopt a value, confirm this using the left-hand display button **Save**.

Volume


Main menu
Settings

Melody




- Select the menu item **Melody** using the lower control button.
- The Melody selection menu is opened by pressing the central Enter button.
- Select the required melody using the control buttons.
- Confirm by pressing the left-hand display button **Save**.

Phone volume
The receiver and handsfree volume are set using the Call volume menu.



- In the Audio settings menu, select the submenu **Call volume** setting using the lower control button.
- Confirm by pressing the left-hand display button OK.

Earpiece volume



- Using the right and left control buttons (+ and -), set the volume in 8 stages.
- If you wish to adopt a value, confirm this using the left-hand display button **Save**.
- Using the lower control button, select **Handsfree** volume.
- Using the right and left control buttons (+ and -), set the **handsfree volume** in multiple stages.
- If you wish to adopt a value, confirm this using the left-hand display button **Save**.


Handsfree

Main menu

Settings

Notifications

In the **Signal tones** menu, acoustic signal tones can be switched on and off for different statuses.




The screenshot shows a menu titled "Audio settings". It contains three options: "Ringtones", "Phone volume", and "Notifications". The "Notifications" option is highlighted with a yellow rectangular border. At the bottom of the screen, there are two buttons: "OK" on the left and "Back" on the right.

Procedure:

- In the Audio settings menu, select the submenu **Signal tones** using the lower control button.
- Confirm by pressing the left-hand display button OK.

Key tones

Each time a button is pressed, an acoustic signal sounds. These **key tones** can be switched on or off here.



The screenshot shows a menu titled "Notifications". It contains three options: "Key tones", "Battery tone", and "Signal tone". Each option has "On" and "Off" sub-options. The "Key tones" option is highlighted with a yellow rectangular border. At the bottom of the screen, there are two buttons: "Save" on the left and "Back" on the right.

- Select the menu item **Key tones** using the lower control button.
- Using the right and left control buttons, select **ON** or **OFF**. Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.

Battery tone

The Scope cordless handset signals a critically low battery status with an acoustic warning. The battery in the cordless handset then requires charging in the charging cradle. This **battery tone** can be switched on or off here.

- Select **Battery tone** using the control button.
- Using the right and left control buttons, select **ON** or **OFF**.
- Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.

Signal tone

Executed functions such as Doormatic activation are signalled by an acoustic tone. A signal tone indicates that an action cannot be performed, e.g. implausible inputs for date or time. This **signal tone** can be switched on or off here.

- Select **Signal tone** using the control button.
- Using the right and left control buttons, select **ON** or **OFF**.
- Your selection is highlighted by a yellow frame.
- Confirm by pressing the left-hand display button OK.

Main menu
Settings

Speed dial

For fast access to favourite users from the phonebook or intercom users or functions, it is possible to assign a speed dialling number from 0 - 9.

Settings

Status

Date and time

Audio settings

Speed dial

Language

System

OK

Back

Speed dial

5

6

7

8

9

I Light

II Last door

Assign

Back

Speed dial

Assign speed dial from
Phonebook Intercom

OK

Back

- Procedure:
- In the Settings menu, select the **Speed dialling** submenu using the lower control button.
 - Confirm by pressing the left-hand display button OK.
 - Select the required Speed dialling number using the control button.
 - Access the Assign speed dial menu using the display button Assign.
 - Speed dialling entries can be assigned from the Phonebook or Intercom.
 - Using the right and left control button, choose between Phonebook or Intercom.

- Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.
- Now select the required **Speed dialling assignment** using the lower control button.
- Confirm by pressing the left-hand display button OK.
- Pressing the red End call button takes you back to the higher-level menu.

Main menu
Settings


Making a speed dialling call




- When the Scope mobile handset is in the ready status, press the assigned number for around 3 seconds. The user is dialled directly.

Frequently used functions

Two frequently used functions or user numbers (so-called softkeys) can be indicated in the display for super-fast access using the two display buttons. For this, buttons I and II are reserved in the speed dialling menu. These two buttons are assigned a name from the phone-book or an intercom function in the speed dialling menu. In the ready mode, you can use the two buttons at the bottom of the display to access frequently used functions such as light switching or opening the garage, or alternatively favourite telephone numbers.



- Frequently used functions:**
Light
Door call



- In the Settings menu, select the **Speed dialling** submenu using the lower control button.
- Confirm by pressing the left-hand display button OK.

Frequently used functions

Speed dial

5

6

7

8

9

I Light

II Last door

Assign

Back

- Select the speed dialling number I (for the left-hand display button) or II (for the right-hand display button) using the lower control button.
- Select the required Speed dialling number using the control button.
- Access the Assign speed dial menu using the display button Assign.
- Speed dialling entries can be assigned from the Phonebook or Intercom.
- Using the right and left control button, choose between Phonebook or Intercom.

Speed dial

Assign speed dial from
Phonebook Intercom

OK

Back

- Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.
- Now select the required **Speed dialling** assignment using the lower control button.
- Confirm by pressing the left-hand display button OK.



- Pressing the red End call button takes you back to the higher-level menu.

Main menu

Settings

Language

In the Language menu, you can select the menu language and the possible special symbols for phonebook entries. There are 10 languages to choose from: Danish, German, English, Spanish, French, Italian, Dutch, Norwegian, Polish and Swedish.

Settings

Status
Date and time
Audio settings
Speed dial

Language

System

OK

Back

Procedure:

- Select the submenu **Language** using the lower control button.
- Confirm by pressing the left-hand display button OK.
- Select the required language using the lower control button.
- Your selection is highlighted by a yellow frame.
- Confirm by pressing the left-hand display button **Save**.

Language

Dansk
Deutsch
English
Español
Français
Italiano
Nederlands

Save

Back

System

In the **System** menu, the general settings of your Scope cordless handset are carried out.

Settings

Status
Date and time
Audio settings
Speed dial
Language

System


OK

Back


Main menu
Settings

ECO mode

In the ECO mode, the transmission output is reduced to a fixed value. This reduction of the radio output is intended to reduce electro smog. The value depends on the distance from the base station. This reduces the range of your Scope cordless handset. In the ECO mode menu, the ECO mode is switched on and off.




- Procedure:
- Select **Eco mode** in the System menu using the lower control button.
 - Confirm by pressing the left-hand display button OK.
 - Using the right and left control buttons, select **ON** or **OFF**.
 - Your selection is highlighted in yellow.
 - Confirm by pressing the left-hand display button OK.



Change PIN

Important system settings are protected against unauthorized access by a 4-digit Personal Identification Number (PIN), as protection against registration and deregistration of the cordless handset or protection of the door release button on the public network telephone. In the Change PIN menu, it is possible to individualize the default PIN number (0000) to any optional 4-digit PIN.



Note
If you forget the PIN, you will need to reset the base station to the default settings (details in the next chapter).

Change PIN

Settings

Change PIN

Enter PIN

OK

<C

Procedure:

- Select **Change PIN** in the System menu using the control button.
- Confirm by pressing the left-hand display button OK.
- Using the numerical keypad, enter the 4-digit PIN you wish to use.
- Confirm by pressing the left-hand display button OK.
- Confirm the new PIN by entering it again.

Settings

Change PIN

Verify PIN

OK

<C

- Confirm by pressing the left-hand display button OK.
- If the entry is correct, the following confirmation appears: **PIN changed**.
- Confirm by pressing the left-hand display button OK.
- If the entry is incorrect, rewrite the second PIN entry with the same 4-digit number sequence.

Settings

Change PIN

PIN changed

OK

Main menu


Settings

Resetting the base station

When the base station is RESET, it returns to the as-delivered status, in other words:

- The PIN is reset to 0000
- All registered cordless handsets are deleted
- The door forwarding function is deleted
- The Doormatic function is deleted
- All the In-Home functions are deleted

(Print out the settings from the BPS or make a note of the functions activated prior to the RESET and enter the same settings when repeating the registration process.)



Procedure:

- Unplug the patch cable for the In-Home bus at the base station.
- The base station can continue to be supplied with power during this process.
- Then press the PROG button (using a paper clip or similar) and hold it in place.
- While you continue to hold down the PROG button, plug the patch cable back into the In-Home bus.
- When the Prog LED flashes twice, you can release the PROG button.

The status LED on the front of the base station flashes to indicate that the RESET is in progress.

- As soon as the status LED flashes green, the RESET process is completed.
- You can now reregister the cordless handsets which you had previously deregistered.

If you did not deregister your cordless handsets before, the following display appears:

Base not found

- Then select the entry **Deregister handset** in the main menu under system settings.
- In answer to the question **Do you want to deregister the handset?** confirm with **Yes**.
- Confirm by pressing the left-hand display button OK.

The following question appears in the display:

Deregistration failed. Register to different base?

- Confirm by pressing the display button OK.

The registration process is started. As soon as the base station has been located, you can begin to use the cordless handset.

Main menu

Settings

Door call

If there are several cordless handsets registered to one base station, it is possible to activate call silencing at any of the cordless handsets in order to ensure that you are not disturbed.

Door call

Allow door call?

Yes No

OK

Back

Procedure:

- Select **Door call** in the System menu using the lower control button.
- Confirm by pressing the left-hand display button OK.
- Using the right and left control buttons, select **Yes** or **No**.
- Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.

The following message appears in the display: **Door call enabled/disabled.**

Deregistering / registering a handset

In the Deactivate / Activate handset menu, it is possible to register or deregister cordless handsets at the base station.

Registration is secured by the default PIN 0000. If you have changed this PIN, your own personal PIN must be used to register.

Deregister handset

Do you want to deregister the handset?

Yes No

OK

Back

- Select **Deregister/register handset** in the System menu using the lower control button.
- Confirm by pressing the left-hand display button OK.
- Using the right and left control buttons, select **Yes** or **No**.
- Your selection is highlighted in yellow.

Depending on the selection, the display shows the following message: **Registration succeeded**

Deregistration aborted

and:

Would you like to register the handset?

- Confirm by pressing the left-hand display button OK.

Dialling pause

If you are operating the Siedle Scope at a telephone system, you may require an external line digit.

It may be necessary to leave a short pause between dialling the prefix and continuing with the call number. The required pause is determined by the customer's own telephone system. There are three dial pause times to choose from: 800 ms, 1600 ms and 3200 ms, or alternatively no pause 0 ms.

Enter the dial pause individually at all the cordless handsets.

Dialling pause

0 ms

800 ms

1600 ms

3200 ms

Save

Back

Select **Dialling pause** in the System menu using the lower control button.

- Confirm by pressing the left-hand display button OK.
- Now select the required length of the dialling pause using the control button.
- Your selection is highlighted by a yellow frame.
- Confirm by pressing the left-hand display button **Save**.

Main menu
Settings

External line digit

Depending on the telephone system, Scope may have to automatically dial the external line digit before the call number.
Enter the external line digit individually at all the cordless handsets.

External line digit

External line digit

0

Automatically add

Yes No

Save

Back

- Select **External line digit** in the System menu using the lower control button.
- Confirm by pressing the left-hand display button OK.
- The **External line digit** entry is selected. Using the numerical keypad, enter the external line digit you wish to use. Generally this is the external line digit: 0.
- Select the **Automatically add** entry using the lower control button.
- Using the right and left control buttons, select **Yes** or **No**.
- Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button **Save**.

Main menu

Phonebook

Phonebook

In the Phonebook menu, you enter your preferred users and have direct access to these users. Up to 50 entries are possible in the phonebook of each of the cordless handsets registered to the base station.



New entry

The customary special symbols for the set language can also be found by multiple pressing of a numerical button.

Sequence of phonebook entries

The phonebook entries are generally alphabetically listed.

Special symbols and numbers have top priority.

If you wish to circumvent the alphabetical sequence of entries, precede the name with a symbol or number. These entries are listed at the top of the phonebook.

Phonebook

OKBack

New entry

Name:

Number:

Save<C

Procedure:

- When your cordless handset is in the ready status, select the **Phonebook** menu directly using the lower control button.

Alternatively:

- In the main menu **Settings**, select the Phonebook symbol by pressing the lower control button.

- Confirm by pressing the left-hand display button OK.

- In the Phonebook menu, the **new entry** is selected.
- Confirm by pressing the left-hand display button OK.
- The entry Name is highlighted in a yellow frame.
- Using the input buttons, enter the name entry you wish to use. There are several letters stored behind each button in the numerical keypad. By pressing the button several times, you move from one letter to the next.
- A short pause between presses will cause the selected letter to appear in your entry.

- Confirm by pressing the left-hand display button **Save**.

- Select the **Number** entry using the lower control button.
- Enter the required number using the numerical keypad.
- Confirm by pressing the left-hand display button **Save**.

Main menu
Phonebook

Phonebook options



The following options are available for making entries in the phonebook:


- **Call**
- **Edit**
- **Delete**

- Select the required phonebook entry using the control buttons.
 - Select **Options** using the display button located on the left below.
- The following Options menu opens:

- **Call**
- **Edit**
- **Delete**

Making a call to a phonebook entry

If your phonebook is very extensive, press on the various letters to jump directly to the names starting with the relevant letter.



- Press the green call button to dial the selected user direct.

or

- Select **Call** in the Phonebook options menu using the lower control button.
- Confirm by pressing the left-hand display button OK.

Call:

The call to the user listed in the phonebook is established. The display changes to the telephony mode.

Change entry

Change entry

Name:

Number:

Save

<C

Procedure:

- Select Change in the Phonebook options menu using the lower control button.

Edit:

The name entry can be edited, extended or deleted here.

- Corrections can be made using the display button <C.
- Select **Number** in the Phonebook options menu using the control buttons.
- The number can be edited, extended or deleted here.
- Confirm by pressing the left-hand display button **Save**.

- Corrections can be made using the display button <C.

Deleting an entry

Deleting an entry

Confirm delete

Yes

No

OK

Back

- Select **Delete** in the Phonebook options menu using the lower control button.

Deleting an entry

- Using the right and left control buttons, select **Yes** or **No**.
- Your selection is highlighted in yellow.
- Confirm by pressing the left-hand display button OK.

Intercom menu

Using the Intercom menu, it is possible to execute functions in the building communication mode.

Examples include:

Switching on the light

Dialling last door



Calling an in-house telephone

Calling another Siedle Scope cordless handset

Viewing the video image at the door station

A maximum of 15 different functions plus a maximum of five additional Scope cordless handsets are possible. The latter are automatically entered by the system.

Your electrical installer programs these functions. Please refer to the separate In-Home Video system manual for the intercom functions.








Procedure:

When your cordless handset is in the ready status, select the **Intercom menu** directly using the left-hand control button.

The display in the status bar shows the **Intercom settings** for the different areas.

- Use the right or left control buttons to switch between the different areas.
- The relevant Intercom symbol precedes each entry in the list.
- If your list contains a large number of entries, use the lower control button to scroll to the next page.

The individual symbols in the Intercom menu

	All intercom functions
	Selectable doors
	Bus telephones: Calls to wired In-Home users
	Scope cordless handsets
	Switching and control functions in the In-Home bus

Frequently asked questions

There is nothing showing in the display.

- 1** The cordless handset is hibernating.
 - Briefly press any optional button.
- 2** The cordless handset is not switched on.
 - Press the red End call button and hold down for a while.
- 3** The battery is empty.
 - Charge the battery or exchange it.

The cordless handset does not ring.

- 1** The ring tone has been switched off
 - Hold down the Star key for 3 seconds.
- 2** The call volume is set to minimum
 - Increase the call volume.
- 3** Door calls are switched off
 - Switch the door calls on.
- 4** Door call forwarding is enabled
 - Disable door call forwarding.

The cordless handset does not respond when buttons are pressed.

- 1** The keypad lock is activated
 - Hold down the Hash key for 3 seconds.

The person at the other end cannot hear you.

- 1** You have set the cordless handset to mute using the microphone symbol
 - Press the microphone symbol again.

The number of the caller is not displayed.

- 1** The caller has withheld their call number.
or
- 2** The number display function has not been enabled.
 - The caller should arrange for number display function to be enabled by their provider.

The display says Base not found

- 1** The cordless handset is out of range of the base station
 - Reduce the distance between the cordless handset and the base station.
- 2** The cordless handset has been deregistered
 - Register the cordless handset.
- 3** The base station has not been switched on
 - Check the power supply unit to the base station.

Error tone after PIN enquiry / forgotten PIN

- 1** You have entered the wrong PIN.
 - Reset the system PIN to the default setting (0000).

You cannot hear a ring tone / dialling tone from the landline.

- 1** You are not using the supplied telephone cable.
 - Please use the supplied telephone cable.
- 2** The telephone cable is not correctly connected to the base station / the telephone network.
 - Check for correct connection.
- 3** Your telephone system requires a (different) external line digit / a (different) dialling pause than the one which is set.
 - When you call your cordless handset from a public network telephone, the display of your cordless handset tells you whether the TC system automatically adds the external line digit for incoming calls or not.
 - Try the various dialling pauses in the Settings > System menu.
 - Take into account the default settings of your telephone system in your Scope cordless handset settings.

It is not possible to call back the numbers entered in the call list

- 1** Your telephone system automatically adds a 0 as a prefix for incoming calls. For this, you have preselected the external line digit 0 in the system settings. Your telephone system saves incoming calls in the call lists with the zero automatically added. This means that you phone the entries in the call list back with a double 0.
 - You can find out the presets of your phone system using the following process:
 - Call your cordless handset from a public network telephone.
 - The display on your cordless handset will tell you about the pre-settings of your telephone system, for instance the prefixed 0.
 - If there is a 0 already entered, select the option No in the system settings under External line digit.
 - Take into account the general default settings of your telephone system in your Scope cordless handset settings.

You receive a call from a public network telephone during a door call.

- If you wish to accept the public network call:
- Reject the door call with the red End call button.
 - Then accept the public network call with the green Pick up button.

If a door call is forwarded, after hanging up only the public network engaged tone is audible at the door.

- Before hanging up, press the button combination * 0 #
- and then end the call by pressing the red hang up button.

Index

A

Audio settings	25
----------------	----

B

Battery charge status	2
Battery tone	27
Brokering	11

C

Call	38
Call forwarding	10
Call parking	9
Call silencing	2
Change PIN	32, 33
Charging	6
Charging cradle	11
Control Device	20
Cordless handset	
deregister	35
register	35

D

Danish	31
Date	12
Default PIN number	32
Dialling pause	35
Directive 2002/96/EC	5
Disposal	5
Disposal of battery	5
Door call	35
Enable	35
Disable	35
Door call forwarding	19
Door functions	40
Door release	11
Door release from	
public network telephone	19
Doormatic	18
Dutch	31

E

ECO mode	32
Ending a call	10
English	31
External line digit	36

F

French	31
Frequently asked questions	42
Frequently used functions	29
function number	21
Function type	20
Functions	20
Functions for	
Scope cordless handsets	40

G

German	31
--------	----

H

Handsfree	8, 15
Handsfree volume	26

I

Idle status	11
Incoming calls	16
Intercom menu	2, 37, 38, 39
Intercom settings	18
Italian	31

K

Key tones	27
Keypad lock	8

L

Language	31
----------	----

M

Main menu	2
Making a speed dialling call	29
Melody	26
Microphone silencing	9
Missed calls	16

N

Name	21
Navigation	2
Norwegian	31
Notifications	27

O

Outgoing calls	16
----------------	----

P

Performance features	4
Personal Identification Number	
PIN	32
Phone volume	2, 15, 16
Phonebook	2, 34, 35, 36
Making a call to a	
phonebook entry	38
Change entry	38
Deleting an entry	38
New entry	37
Phonebook options	38
Polish	31

R

Reception quality	2
Register additional	
cordless handsets	6
Ringtones	25

S

Security awareness	4
Settings	22
Signal tone	27
Spanish	31
Speed dial	28
Standby mode	2
Status	22
Status display	2
Swedish	31
Switching and control functions	40
System	31

T

Time	12, 13, 23
Type	20, 21

V

Video	14, 15
Volume	2, 9, 25

W

Wired	20
-------	----

SSS SIEDLE

S. Siedle & Söhne

Postfach 1155
78113 Furtwangen
Bregstraße 1
78120 Furtwangen

Telefon +49 7723 63-0
Telefax +49 7723 63-300
www.siedle.de
info@siedle.de
Germany

© 2011/07.11
Printed in Germany
Best. Nr. 0-1106/141359 EN